

Disinfecting Morbern Coated Fabrics

General disinfection

Bleach

Dilute the bleach up to a 9:1 ratio (10%). Liberally apply diluted bleach solution using a sponge. Rinse with cold water several times. Wipe dry. Be sure to follow the guidelines on the bleach label.

Isopropyl Alcohol

Isopropyl Alcohol with concentration of around 70% can kill coronaviruses. Leave the 70% Isopropyl Alcohol solution for one minute. Follow this with several clean water rinses before wiping dry.

Hydrogen Peroxide

Hydrogen Peroxide with a 3% concentration can be applied. Hydrogen Peroxide with a 3% concentration can be applied to the product and allowed to sit for one minute. Follow this with several clean water rinses before wiping dry.

For use of specific Healthcare Disinfectant Cleaners, please refer to the Morbern Healthcare Guide.

Please note that these disinfectants are not cleaners for stains or dirt, which help combat lingering bacteria and virus pathogens.

It is always best to practice on an inconspicuous area first to be sure it does not negatively affect the coated fabric. From there you can expand to the area you need to disinfect.

This document does not contain medical advice. The information is provided in good faith for general informational and educational purposes only and is not a substitute for professional advice. We make no representation or warranty of any kind, express or implied, regarding the accuracy, adequacy, validity, reliability, availability or completeness of any information on this document.

Under no circumstance shall Morbern accept any liability for any loss or damage of any kind incurred as a result of the use of the information on this document.

Please adhere to the manufacturer's instructions. For more information, we recommend visiting Disinfection of environments in healthcare and non- healthcare settings potentially contaminated with SARS-CoV-2 as listed on the European Centre for Disease Prevention and Control.

